



screw the three-section poles into the base

1



extend out telescopic crossbar assemblies

2



slide image/graphics pole pockets overtop and bottom crossbars

3



secure top and bottom crossbars to upright position using the provided knobs

4



raise telescopic tube upright until graphic/image is taut, then lock

5

Applicable Products:

8'x8' / 8'x9' / 8'x10' Black Stands

**Adjustable Width/Height
Banner Stands assembly**

goldimageprinting.com

